




# PARTS INFORMATION

## HT-200



Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.
1	HT-200-001	Starter Handle	1	31	HT-200-031	Screw 5*18/S	4	61	HT-200-061	Space, Carburetor	1
2	HT-200-002	Handle Insulator	1	32	HT-200-032	Spark Plug	1	62	HT-200-062	Gasket, Carburetor Space	2
3	HT-200-003	Recoil Starter Case.	1	33	HT-200-033	Engine Shroud	1	63	HT-200-063	Inlet Manifold	1
4	HT-200-004	Recoil Spring	1	34	HT-200-034	Clamp	1	64	HT-200-064	Screw 5*25/SW	2
5	HT-200-005	Starter Rope Reel	1	35	HT-200-035	Screw 5*20/SW	2	65	HT-200-065	Throttle Wire	1
6	HT-200-006	Starter Rope	1	36	HT-200-036	Clip for Crank Case	1	66	HT-200-066	Carburetor	1
7	HT-200-007	Starter Pawl	1	37	HT-200-037	Clamp	1	67	HT-200-067	Air Cleaner Body	1
8	HT-200-008	Clip	1	38	HT-200-038	Screw	1	68	HT-200-068	Sponge	1
9	HT-200-009	Starter Retainer	1	39	HT-200-039	Plate	1	69	HT-200-069	Air Cleaner Cap	1
10	HT-200-010	5*12 Screw	1	40	HT-200-040	Screw 5*10/SW	1	70	HT-200-070	Screw 4*40/SW	2
11	HT-200-011	M8 Nut	1	41	HT-200-041	Magneto Rotor	1	71	HT-200-071	Fuel Tank	1
12	HT-200-012	Starter Pulley	1	42	HT-200-042	Ignition Coil	1	72	HT-200-072	Oil Hose	1
13	HT-200-013	Screw	4	43	HT-200-043	Screw 5*20/SW	2	73	HT-200-073	Oil Hose Clip	2
14	HT-200-014	Crank Case Assy' 1	1	44	HT-200-044	Nut M8	1	74	HT-200-074	Tank Inner Cap	1
15	HT-200-015	Oil Seal 12 22 7	1	45	HT-200-045	Washer M8	1	75	HT-200-075	Tank Cap Compressor	1
16	HT-200-016	Ball Bearing 6202 C3	1	46	HT-200-046	Clutch Arm Comp.	2	76	HT-200-076	Tank Cap	1
17	HT-200-017	Crank Shaft	1	47	HT-200-047	Clutch Spring	1	77	HT-200-077	Fuel Tank Band	1
18	HT-200-018	Semicircle Key	1	48	HT-200-048	Wavy Washer	2	78	HT-200-078		
19	HT-200-019	Crank Case Gasket	1	49	HT-200-049	Clutch Step Bolt	2	79	HT-200-079		
20	HT-200-020	Ball Bearing 6202 C3	1	50	HT-200-050	Fan Case	1	80	HT-200-080		
21	HT-200-021	Oil Seal 15 35 7	1	51	HT-200-051	Stop Switch	1	81	HT-200-081	Fuel Tank Holder	1
22	HT-200-022	Crank Case Assy' 2	1	52	HT-200-052	Screw	1	82	HT-200-082	Fuel Tank Rubber	4
23	HT-200-023	Screw 5*30/S	4	53	HT-200-053	Screw 5*25/SW	3	83	HT-200-083	Screw	2
24	HT-200-024	Needle Bearing	1	54	HT-200-054	Gasket, Muffler	1				
25	HT-200-025	Cylinder Gasket	1	55	HT-200-055	Muffler Comp.	1				
26	HT-200-026	Piston Ring	2	56	HT-200-056	Muffler Bolt	2				
27	HT-200-027	Piston	1	57	HT-200-057	Nut M5	2				
28	HT-200-028			58	HT-200-058	Muffler Protector	1				
29	HT-200-029			59	HT-200-059	Screw 5*10/SW	1				
30	HT-200-030	Cylinder	1	60	HT-200-060	Screw 4*12/SW	1				