




PARTS INFORMATION

NB-411




Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.
1	NB-411-001	Starter Handle	1	22	NB-411-022	Piston Ass'y	1	43	NB-411-043	Clutch Step Bolt	3	64	NB-411-064	O-Ring	1	85	NB-411-085	Fuel Cock Gasket	1
2	NB-411-002	Recoil Starter Body	1	23	NB-411-023	Piston Ring	2	44	NB-411-044	Clutch Spring	3	65	NB-411-065	Wing Screw	1	86	NB-411-086	Fuel Cock Ass'y	1
3	NB-411-003	Recoil Spring	1	24	NB-411-024	Cylinder Gasket	1	45	NB-411-045	Clutch Ass'y	1	66	NB-411-066	Plate	1	87	NB-411-087	Screw	2
4	NB-411-004	Starter Rope	1	25	NB-411-025	Cylinder	1	46	NB-411-046	Washer	1	67	NB-411-067	Screw	2	88	NB-411-088	Screw	2
5	NB-411-005	Starter Rope Reel	1	26	NB-411-026	Screw	4	47	NB-411-047	Spring Washer	1	68	NB-411-068	Spring	1	89	NB-411-089	Nut	1
6	NB-411-006	Ratchet	1	27	NB-411-027	Spark Plug	1	48	NB-411-048	Lead Valve Gasket	1	69	NB-411-069	Adjust Screw	1	90	NB-411-090	Air Cleaner Case	1
7	NB-411-007	Washer	1	28	NB-411-028	Engine Cover	1	49	NB-411-049	Lead Valve Ass'y	1	70	NB-411-070	Piston Valve	1	91	NB-411-091	Spacer	2
8	NB-411-008	Ratchet Guide	1	29	NB-411-029	Screw	1	50	NB-411-050	Insulator Gasket	1	71	NB-411-071	Packing	1	92	NB-411-092	Screw	2
9	NB-411-009	Friction Spring	1	30	NB-411-030	Wood-Ruff Key	1	51	NB-411-051	Insulator	1	72	NB-411-072	Jet Needle	1	93	NB-411-093	Circle Sponge	1
10	NB-411-010	Washer	1	31	NB-411-031	Magneto Rotor	1	52	NB-411-052	Screw	2	73	NB-411-073	E-Ring	1	94	NB-411-094	Trapezoid Sponge	1
11	NB-411-011	Bind Screw	1	32	NB-411-032	Washer	1	53	NB-411-053	Carburetor Gasket	1	74	NB-411-074	Packing	1	95	NB-411-095	Air Cleaner Cover	1
12	NB-411-012	Oil Seal	2	33	NB-411-033	Screw	1	54	NB-411-054	Carburetor Body	1	75	NB-411-075	Spring Plate	1	96	NB-411-096	Screw	1
13	NB-411-013	Crank Case (A)	1	34	NB-411-034	Spark Plug Cap	1	55	NB-411-055	Main Jet	1	76	NB-411-076	Throttle Valve Spring	1	97	NB-411-097	Muffler Gasket	1
14	NB-411-014	Crank Case Gasket	1	35	NB-411-035	Spark Plug Cap Spring	1	56	NB-411-056	Needle Ass'y	1	77	NB-411-077	Cap	1	98	NB-411-098	Muffler	1
15	NB-411-015	6202 C3 Ball Bearing	2	36	NB-411-036	Ignition Coil	1	57	NB-411-057	Float Arm	1	78	NB-411-078	Cable Guide	1	99	NB-411-099	Screw	2
16	NB-411-016	Crank Shaft	1	37	NB-411-037	Screw	2	58	NB-411-058	Straight Pin	1	79	NB-411-079	Nut	1	100	NB-411-100	Muffler Cover	1
17	NB-411-017	Pin	2	38	NB-411-038	Clutch Seat	1	59	NB-411-059	Float	1	80	NB-411-080	Cable Adjuster	1	101	NB-411-101	Screw	1
18	NB-411-018	Crank Case (B)	1	39	NB-411-039	Clutch Shoe	3	60	NB-411-060	Float Body Gasket	1	81	NB-411-081	Cap	1	102	NB-411-102	Screw	1
19	NB-411-019	Needle Bearing	1	40	NB-411-040	Bow Washer	3	61	NB-411-061	Float Body	1	82	NB-411-082	Hose	1	103	NB-411-103	Washer	1
20	NB-411-020	Piston Ass'y	1	41	NB-411-041			62	NB-411-062			83	NB-411-083	Filter	1	104	NB-411-104	Screw	1
21	NB-411-021			42	NB-411-042			63	NB-411-063			84	NB-411-084			105	NB-411-105	Screw	1
																126			



PARTS INFORMATION

KBC-2600-A4



Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.
1	KBC-2600-A4-01	26MM GEAR CASE	1	31	KBC-2600-A4-31	SCREW	2	61	KBC-2600-A4-61	SHAFT FOR ENGINE BASE COMP.	1
2	KBC-2600-A4-02	7*16T GEAR PINION	1	32	KBC-2600-A4-32	NUT	2	62	KBC-2600-A4-62	SCREW	3
3	KBC-2600-A4-03	6000 ZZ BEARING	1	33	KBC-2600-A4-33	SCREW	1	63	KBC-2600-A4-63	CAP FOR BEARING	1
4	KBC-2600-A4-04	6000 BEARING	1	34	KBC-2600-A4-34	JOINT PIPE	1	64	KBC-2600-A4-64	6202 BEARING	2
5	KBC-2600-A4-05	S-10 STOP RING	1	35	KBC-2600-A4-35	SCREW	1	65	KBC-2600-A4-65	HOLDER	1
6	KBC-2600-A4-06	R-26 STOP RING	1	36	KBC-2600-A4-36	SHAFT GRIP	1	66	KBC-2600-A4-66	NUT	6
7	KBC-2600-A4-07	629 BEARING	1	37	KBC-2600-A4-37	26MM HANDLE	1	67	KBC-2600-A4-67	SCREW	6
8	KBC-2600-A4-08	10*20T GEAR PINION	1	38	KBC-2600-A4-38	SCREW	4	68	KBC-2600-A4-68	SPRING	3
9	KBC-2600-A4-09	GEAR SHAFT	1	39	KBC-2600-A4-39	26MM HANDLE BRACKET A	1	69	KBC-2600-A4-69	NUT	3
10	KBC-2600-A4-10	6201-K1 BEARING	1	40	KBC-2600-A4-40	NUT	4	70	KBC-2600-A4-70	WASHER	1
11	KBC-2600-A4-11	R-32 STOP RING	1	41	KBC-2600-A4-41	SAFETY GUARD COMP.	1	71	KBC-2600-A4-71	NUT	1
12	KBC-2600-A4-12	CAP	1	42	KBC-2600-A4-42	SAFETY GUARD SET PLATE	1				
13	KBC-2600-A4-13	SCREW	3	43	KBC-2600-A4-43	SCREW	2				
14	KBC-2600-A4-14	CUTTER HOLDER	1	44	KBC-2600-A4-44	CLUTCH CASE	1				
15	KBC-2600-A4-15	CUTTER HOLDER CAP	1	45	KBC-2600-A4-45	S-15 STOP RING	1				
16	KBC-2600-A4-16	NUT HOLDER CAP	1	46	KBC-2600-A4-46	6002 ZZ BEARING	1				
17	KBC-2600-A4-17	10MM NUT (L.)	1	47	KBC-2600-A4-47	R-32 STOP RING	1				
18	KBC-2600-A4-18	WASHER	1	48	KBC-2600-A4-48	CLUTCH DRUM COMP	1				
19	KBC-2600-A4-19	SCREW	1	49	KBC-2600-A4-49						
20	KBC-2600-A4-20	26*1.75*1290 DRIVE SHAFT COMP.	1	50	KBC-2600-A4-50						
21	KBC-2600-A4-21	7*14*14 BUSHING ASS'Y	5	51	KBC-2600-A4-51	SNAP PIN	1				
22	KBC-2600-A4-22	23MM CUSHION RUBBER COMP.	5	52	KBC-2600-A4-52						
23	KBC-2600-A4-23	7T*1365 DRIVE SHAFT COMP.	1	53	KBC-2600-A4-53						
24	KBC-2600-A4-24	BEARING COVER	1	54	KBC-2600-A4-54	A3 SHOULDER STRAP	2				
25	KBC-2600-A4-25	627 ZZ BEARING	1	55	KBC-2600-A4-55	A3 SHOULDER PLATE COMP.	1				
26	KBC-2600-A4-26	NUT	1	56	KBC-2600-A4-56	A3 SHOULDER FRAME COMP.	1				
27	KBC-2600-A4-27	7MM ADAPTOR	1	57	KBC-2600-A4-57	SCREW	4				
28	KBC-2600-A4-28	SCREW	1	58	KBC-2600-A4-58	CLIP FOR SHOULDER FRAME COMP.	2				
29	KBC-2600-A4-29	SCREW	1	59	KBC-2600-A4-59	NUT	1				
30	KBC-2600-A4-30	J TYPE THROTTLE LEVER	1	60	KBC-2600-A4-60	ENGINE BASE COMP.	1				