




# PARTS

# INFORMATION

# FTP-21



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	FTP21-001B	Φ78 Clutch Drum	1	25	FTP21-025	Suction Valve Collar	2	51	FTP21-051	Screw	4
1	FTP21-001S	Φ54 Clutch Drum	1	26	FTP21-026	Overflow Valve	2	52	FTP21-052	Overflow Pipe	1
2	FTP21-002	Screw	4	27	FTP21-027	Seal Seat	2				
3	FTP21-003B	Φ88 Drum Case	1	28	FTP21-028	27*2 O-Ring	2				
3	FTP21-003S	Φ66 Drum Case	1	29	FTP21-029	16 24 6 Oil Seal	2				
4	FTP21-004	Φ4*11.8 Pin	2	30	FTP21-030	Drainage Seat	2				
5	FTP21-005	6000 Bearing	2	31	FTP21-031	16 24 4 Oil Seal	2				
6	FTP21-006	Gear	1	32	FTP21-032	Crank Case	1				
7	FTP21-007	6001 Bearing	2	33	FTP21-033	Pipe Plug	1				
8	FTP21-008	Shaft	1	34	FTP21-034	Crank Case Cover	1				
9	FTP21-009	Cover of Drum Case	1	35	FTP21-035	Screw	4				
10	FTP21-010	Eccentric Cam	1	36	FTP21-036	Suction Pipe	1				
11	FTP21-011	6004 Bearing	1	37	FTP21-037	16mm Plunger	1				
12	FTP21-012	21mm Cylinder Pipe	2	38	FTP21-038	Overflow Chamber	1				
13	FTP21-013	22*2 O-Ring	2	39	FTP21-039	9.8*2.4 O-Ring	1				
14	FTP21-014	29.82*2.62 O-Ring	2	40	FTP21-040	Pressure Valve Fixed Seat	1				
15	FTP21-015	Valve Seat	2	41	FTP21-041	12.37*2.62 O-Ring	1				
16	FTP21-016	Valve Plug Plug	2	42	FTP21-042	Pressure Valve	1				
17	FTP21-017	Valve Spring	2	43	FTP21-043	Spring	1				
18	FTP21-018	Connector	2	44	FTP21-044	Pressure Valve Rod	1				
19	FTP21-019	P9 O-Ring	5	45	FTP21-045	Pressure Valve Shaft	1				
20	FTP21-020	Outlet Chamber	1	46	FTP21-046	Pressure Valve Case	1				
21	FTP21-021	Screw	8	47	FTP21-047	Pressure Fixed Seat	1				
22	FTP21-022	Screw	2	48	FTP21-048	Pressure Adjustment	1				
23	FTP21-023	Suction Valve	2	49	FTP21-049	Washer	1				
24	FTP21-024	21mm Piston	2	50	FTP21-050	M6 Nylon Nut	1				