




PARTS

INFORMATION

FTC-16



Item	Part No.	Description	Qty.	Unit Price	Item	Part No.	Description	Qty.	Unit Price	Item	Part No.	Description	Qty.	Unit Price
1	FTC16-001B	Φ78 Clutch Drum	1		25	FTC16-025	Adjusting Ring	2		51	FTC16-051	6201 Bearing	1	
1	FTC16-001S	Φ54 Clutch Drum	1		26	FTC16-026	Fixed Seat	2		52	FTC16-052	Φ12*17 Pipe	1	
2	FTC16-002	TC 17 28 7 Oil Seal	1		27	FTC16-027	P15 O-Ring	2		53	FTC16-053	Grease Seat	2	
3	FTC16-003B	Φ88 Drum Case	1		28	FTC16-028	TC 16 28 7 Oil Seal	2		54	FTC16-054	Grease Cup	2	
3	FTC16-003S	Φ66 Drum Case	1		29	FTC16-029	Screw	4		55	FTC16-055	P22 O-Ring	1	
4	FTC16-004	Screw	12		30	FTC16-030	Front Cover	1		56	FTC16-056	Oil Glass	1	
5	FTC16-005	608 Ball Bearing	1		31	FTC16-031	G58 O-Ring	1						
6	FTC16-006	Gasket	1		32	FTC16-032	Gear Case	1						
7	FTC16-007	Φ6*16 Pin	2		33	FTC16-033	Φ16*166 Plunger	1						
8	FTC16-008	Gear	1		34	FTC16-034	18mm Clip	2						
9	FTC16-009	6203 Bearing	1		35	FTC16-035	Suction Hose	1						
10	FTC16-010	6200 Bearing	1		36	FTC16-036	Cylinder Right	1						
11	FTC16-011	Screw	1		37	FTC16-037	M6 Nylon Nut	1						
12	FTC16-012	P9 O-Ring	5		38	FTC16-038	Washer	1						
13	FTC16-013	13cm High Pressure Hos	1		39	FTC16-039	Pressure Adjuster	1						
14	FTC16-014	Outlet Chamber A	1		40	FTC16-040	3/4"-16 UNF Nut	1						
15	FTC16-015	1/2" Valve Ass'y	4		41	FTC16-041	Pressure Valve Shaft	1						
16	FTC16-016	Suction Chamber	2		42	FTC16-042	Spring	1						
17	FTC16-017	Screw	4		43	FTC16-043	1/8"PF 28 Pipe	1						
18	FTC16-018	Suction Pipe	1		44	FTC16-044	Pressure Valve Case	1						
19	FTC16-019	Pipe Plug	3		45	FTC16-045	Valve Rod	1						
20	FTC16-020	Cylinder Left	1		46	FTC16-046	8mm Valve Ball	1						
21	FTC16-021	Parking Seat	2		47	FTC16-047	Valve Seat	1						
22	FTC16-022	V-Packing	4		48	FTC16-048	Outlet Chamber B	1						
23	FTC16-023	Grease Seat	2		49	FTC16-049	HK1010 Needle Bearing	1						
24	FTC16-024	Grease Packing	2		50	FTC16-050	Gear Shaft	1						