




PARTS INFORMATION

NB-411




Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.				
1	NB-411-001	Starter Handle	1	21	NB-411-021	Piston Ass'y	1	42	NB-411-042	Bow Washer	3	63	NB-411-063	Screw	2	84	NB-411-084	Screw	2	105	NB-411-105	Fuel Tank Bracket	1
2	NB-411-002	Recoil Starter Body	1	22	NB-411-022	Piston Ass'y	1	43	NB-411-043	Clutch Step Bolt	3	64	NB-411-064	Spring	1	85	NB-411-085	Nut	1	106	NB-411-106	Spacer	2
3	NB-411-003	Recoil Spring	1	23	NB-411-023	Piston Ass'y	2	44	NB-411-044	Clutch Spring	3	65	NB-411-065	Adjust Screw	1	86	NB-411-086	Air Cleaner Case	1	107	NB-411-107	Screw	2
4	NB-411-004	Starter Rope	1	24	NB-411-024	Piston Ring	2	45	NB-411-045	Lead Valve Gasket	1	66	NB-411-066	Piston Valve	1	87	NB-411-087	Spacer	2	108	NB-411-108	Fuel Tank Cap	1
5	NB-411-005	Starter Rope Reel	1	25	NB-411-025	Cylinder Gasket	1	46	NB-411-046	Lead Valve Ass'y	1	67	NB-411-067	Packing	1	88	NB-411-088	Screw	2	109	NB-411-109	Cap Inner Plate	1
6	NB-411-006	Ratchet	1	26	NB-411-026	Cylinder	1	47	NB-411-047	Insulator Gasket	1	68	NB-411-068	Jet Needle	1	89	NB-411-089	Circle Sponge	1	110	NB-411-110	Cap Sponge	1
7	NB-411-007	Washer	1	27	NB-411-027	Screw	4	48	NB-411-048	Nut	2	69	NB-411-069	E-Ring	1	90	NB-411-090	Trapezoid Sponge	1	111	NB-411-111	Cap Inner	1
8	NB-411-008	Ratchet Guide	1	28	NB-411-028	Spark Plug	1	49	NB-411-049	Insulator	1	70	NB-411-070	Packing	1	91	NB-411-091	Air Cleaner Cover	1	112	NB-411-112	Cap Inner	1
9	NB-411-009	Friction Spring	1	29	NB-411-029	Engine Cover	1	50	NB-411-050	Screw	2	71	NB-411-071	Spring Plate	1	92	NB-411-092	Screw	1	113	NB-411-113	Fuel Tank Cap	1
10	NB-411-010	Washer	1	30	NB-411-030	Screw	1	51	NB-411-051	Carburetor Gasket	1	72	NB-411-072	Throttle Valve Spring	1	93	NB-411-093	Muffler Gasket	1	114	NB-411-114	Fuel Filter	1
11	NB-411-011	Bind Screw	1	31	NB-411-031	Screw	1	52	NB-411-052	Carburetor Body	1	73	NB-411-073	Mixing Cap	1	94	NB-411-094	Muffler	1	115	NB-411-115	Fuel Filter Gasket	1
12	NB-411-012	Oil Seal	2	32	NB-411-032	Wood-Ruff Key	1	53	NB-411-053	Main Jet	1	74	NB-411-074	Cap	1	95	NB-411-095	Screw	2	116	NB-411-116	Fuel Tank	1
13	NB-411-013	Crank Case (A)	1	33	NB-411-033	Magneto Rotor	1	54	NB-411-054	Needle Ass'y	1	75	NB-411-075	Cable Guide	1	96	NB-411-096	Muffler Cover	1	117	NB-411-117	Hose Clamp	1
14	NB-411-014	Crank Case Gasket	1	34	NB-411-034	Washer	1	55	NB-411-055	Float Arm	1	76	NB-411-076	Nut	1	97	NB-411-097	Screw	1	118	NB-411-118	Tube Fuel	1
15	NB-411-015	6202 C3 Ball Bearing	2	35	NB-411-035	Screw	1	56	NB-411-056	Straight Pin	1	77	NB-411-077	Cable Adjuster	1	98	NB-411-098	Screw	1	119			
16	NB-411-016W10	Crank Shaft	1	36	NB-411-036	Spark Plug Cap	1	57	NB-411-057	Float	1	78	NB-411-078	Cap	1	99	NB-411-099	Washer	1	120			
	NB-411-016W15	Crank Shaft For 1.5"	1	37	NB-411-037	Spark Plug Cap	1	58	NB-411-058	Float Body Gasket	1	79	NB-411-079	Hose	1	100	NB-411-100	Screw	1	121			
17	NB-411-017	Pin	1	38	NB-411-038	Ignition Coil	1	59	NB-411-059	Float Body	1	80	NB-411-080	Filter	1	101	NB-411-101	Screw	1	122			
18	NB-411-018	Crank Case (B)	1	39	NB-411-039	Screw	2	60	NB-411-060	O-Ring	1	81	NB-411-081	Fuel Cock Gasket	1	102	NB-411-102	Screw	1	123			
19	NB-411-019	Screw	4	40	NB-411-040	Clutch Seat	1	61	NB-411-061	Wing Screw	1	82	NB-411-082	Fuel Cock Ass'y	1	103	NB-411-103	Damper	1	124			
20	NB-411-020	Needle Bearing	1	41	NB-411-041	Clutch Shoe	3	62	NB-411-062	Plate	1	83	NB-411-083	Screw	2	104	NB-411-104	Damper	1	125			



PARTS INFORMATION

WATER PUMP-WPL



Item	Part No.	Description	QTY.	Item	Part No.	Description	QTY.
1	WPL-01	PLUG SET	2	21	WPL-21	VOLUTE CASING	1
2	WPL-02	O-RING	2	22	WPL-22	O-RING	1
3	WPL-03	DELIVERY FLANGE	1	23	WPL-23	H BASE	1
4	WPL-04	HEXAGON BOLT	7	24	WPL-24	RUBBER MAT	4
5	WPL-05	DELIVERY FLANGE PACKING	1				
6	WPL-06	PUMP CASING	1				
7	WPL-07	HEXAGON BOLT	2				
8	WPL-08	HEXAGON BOLT	2				
9	WPL-09	HEXAGON BOLT	2				
10	WPL-10	CHECK VALVE	1				
11	WPL-11	SUCTION FLANGE	1				
12	WPL-12	FLANGE NUT	4				
13	WPL-13	FLANGE BRACKET	1				
14	WPL-14	HANDLE SET	1				
15	WPL-15	THROTTLE LEVER	1				
16	WPL-16	THROTTLE WIRE COMP.	1				
17	WPL-17	HEXAGON SOCKETBOLT AND SEAL WASHER	4				
18	WPL-18	O-RING	1				
19	WPL-19	MECHANICAL SEAL	1				
20	WPL-20	IMPELLER	1				